






## SCHEMA DI MONTAGGIO - ASSEMBLY SCHEDULE

COD. **58.0759.00 / 58.0760.00**

REV. **00** DEL. **30/11/2016** TEC-LOG **G.D.**

Descrizione **Seat Ibiza(6P) Cupra**

**Fig. 1**






-  Smontare la cornice dal paraurti originale.
-  Remove the frame of the original bumper.
-  Retirer le cadre du pare-chocs d'origine.
-  Quitar el borde del paragolpes original.
-  Entfernen Sie den Rahmen der Serienstoßstange.



**Fig. 1**




**Fig. 3**

-  Tagliare la parte di lamiera indicata nella foto.
-  Cut a part of the sheet as shown in the picture.
-  Couper une partie de la tôle, comme indiqué dans l'image.
-  Cortar la chapa, como en la imagen.
-  Schneiden Sie einen Teil des Bleches, wie in der Abbildung gezeigt.



**Fig. 4**

-  Incollare il tessuto paracalore al paraurti
-  Pate the heat shield fabric to the bumper.
-  Coller le tissu de protection thermique au pare-chocs.
-  Pegar al paragolpes el tejido de protección térmica.
-  Kleben Sie den Hitzeschutzstoff an die Stoßstange.

